

Air Pincette


Features

- The Air Pincette, incorporating a Vacuum Pad and Vacuum Generator in the pen-shaped body, serves well in the assembly operation of small parts.
- VTB with a built-in valve features low noise and energy saving by flowing air only during service.


Specifications

| | | |
|---------------------------|------------------------------|----------------------|
| Fluid admitted | Air | |
| Service pressure range | 21.3~100psi | 0.15~0.7MPa |
| Rated supply pressure | 71.1psi | 0.5MPa |
| Final vacuum | -26.8in. Hg(VTB:-25.6in. Hg) | -91KPa(VTB : -87KPa) |
| Service temperature range | 32~140°F | 0~60°C |

Model Designation (Example)



Model Designation for ordering Air pincette alone



| | | | | | |
|----------|----------------|-----------|-----------|-----------|-----------|
| Code | Nitrile rubber | 2RN | 4RN | 6RN | 8RN |
| | Silicon rubber | 2RS | 4RS | 6RS | 8RS |
| Pad dia. | | φ2mm | φ4mm | φ6mm | φ8mm |
| | | φ0.079in. | φ0.157in. | φ0.236in. | φ0.315in. |

⚠ Detailed Safety Instructions

Before using the PISCO device, be sure to read the "Safety Instructions", "Common Safety Instructions for Products Listed in This Manual" on pages 23~24 and "Common Safety Instructions for Vacuum" on pages 379~380.


⚠ Caution

1. Do not operate the push-button of the Air Pincette with valve by the machine. Such an operation may damage the button.
2. The filter element can be replaced by removing the ejector (VTA type) or the pad holder (VTB type). Carry out periodic maintenance and checks, or clogging may lower the performance.
3. Note that the silencer element of the Air Pincette with valve can not be replaced.
4. Use a coiling tube for piping to the Air Pincette to minimize the load on the joint.


Vacuum Series Air Pincette

How to use

VTA




VTB



■ Send compressed air of 0.5MPa(72.5psi) to the air pincette. Close the side hole (the push button) with your finger to hold the work under suction. And open the side hole (the push button) to release the work.

VTA

Air Pincette




unit:mm

| Model | Pad dia. φd | A | B | F | Mass (g) |
|-----------|-------------|-----|-------|----|----------|
| VTA-□-2□□ | 2 | 8 | 181.5 | 64 | 21.5 |
| VTA-□-4□□ | 4 | 8 | 181.5 | 64 | 21.5 |
| VTA-□-6□□ | 6 | 11 | 184.5 | 66 | 22.5 |
| VTA-□-8□□ | 8 | 9.5 | 183 | 66 | 22.5 |



VTB

Valve Air Pincette



unit:mm

| Model | Pad dia. φd | A | F | Mass (g) |
|-----------|-------------|-----|------|----------|
| VTB-W-2R□ | 2 | 9 | 59 | 16 |
| VTB-W-4R□ | 4 | 9 | 59 | 16 |
| VTB-W-6R□ | 6 | 11 | 61 | 17 |
| VTB-W-8R□ | 8 | 9.5 | 59.5 | 17 |



VTA PACKAGE

Air Pincette Package

Model : VTA-□-SET



VTB PACKAGE


Valve Air Pincette Package

Model : VTB-W-SET



UL

Coiling Tube



● Products packed

Air pincette

φ2 Pad Rubber (Silicon)

φ4 Pad Rubber (Silicon)

φ6 Pad Rubber (Silicon)

φ8 Pad Rubber (Silicon)

Adapter for φ2 φ4 Pad

Adapter for φ6 φ8 Pad

Coiling Tube (color)