



Release head/release lever

type of construction	max. load in pull direction	A mm	B mm	C mm	D mm	D1 Ø mm	E Ø mm	F mm	G mm	H mm	M1 mm	Nut(SW)	Piston rod at screwed depth	
20AK08U8*1	7.000 N	37	30	38	R8,5	8,1-0,05	17	SW11	20	38,5	M8*1	SW13	9 mm	
20AKXXUXX	7.000 N	37	30	40	R8,5	10,1-0,05	17	SW11	20	38,5	M10*1	SW17	7 mm	
20AK10U10*1	12.000 N	54	39	50	R14	10,1-0,05	21	SW14	26	53	M10*1	SW17	8 mm	
20AK12U10*1	12.000 N	54	39	50	R14	12,1-0,05	21	SW14	26	53	M10*1	SW17	8 mm	
20AK12U14*1,5	12.000 N	54	39	50	R14	12,1-0,05	21	SW14	26	53	M14*1,5	SW19	8 mm	
20AK14U14*1,5	12.000 N	54	39	50	R14	14,1-0,05	21	SW14	26	53	M14*1,5	SW19	8 mm	

Release lever “in function”

1
20AKXXMXX
standard release head

2a
release lever (Release dir. towards the gas spring)

2b
release lever (Release dir. away from the gas spring)

X
pivot point

Flat grip for release lever

20FGS

Flat grip for release lever

